AERA CYLINDER

Wall

LUMENWERX



This product must be installed in accordance with the National Electrical Code and all applicable local codes, by a person familiar with the construction and operation of the product, and the hazards involved. Proper grounding is required for safety.

Ce produit doit être installé suivant le code national de l'électricité, ainsi que tous les codes locaux applicables, par une personne familière avec la construction et le fonctionnement du produit, ainsi que tous les risques qui y sont associés. La mise à terre électrique est obligatoire pour la sécurité.




Wire dimming conductors as Class 1.




For electrical connections, follow the wiring diagrams on page <u>4 and 5</u> according to specified drivers in product configuration.

OVERVIEW


Junction box (by others)






Standard 4" octagonal junction box

Flat canopy



Direct mount




Items list

1	Standard J-box (by others)
2	Mounting plate
3	Flat canopy
4	Direct feed bracket
5	Cylinder

Tools required

- Allen key 5/64
- Philips screwdriver
- Gypsum cutter or milling hand







Shown with Direct/Indirect and also applies to Direct and Indirect.



AERA CYLINDER


LUMENWERX


Wall

FLAT CANOPY -

1 DETACH MOUNTING PLATE.

Loosen the set screws [A] from the canopy [B] to detach the mounting plate [C].






2 FIX MOUNTING PLATE.

Fix the mounting plate **[C]** onto the junction box **[D]** with screws **[E]**.


Note: Make sure the mounting plate is leveled.



3 MAKE ELECTRICAL CONNECTIONS.


Make electrical connections between the fixture cable **[F]** and the main power **[G]** using wire nuts (by others).


Warning: A luminaire with more than one power supply connection means shall be connected to only one branch circuit.



4 MOUNT CANOPY.

Place the housing assembly **[H]** over the mounting plate **[C]** and tighten the set screws **[A]**.







AERA CYLINDER


LUMENWERX


Wall

DIRECT MOUNT -

DETACH DIRECT FEED BRACKET.

Loosen the set screws [A] from the housing assembly [B] to detach the direct feed bracket [C].







2 FIX DIRECT FEED BRACKET.

Locate where the fixture will be installed. Use the direct feed bracket **[C]** as a model to mark a 7/8" dia hole.

Pierce a 7/8" dia hole and fix the direct feed bracket **[C]** with #8 screws **[D]** on the wall.






3 MAKE ELECTRICAL CONNECTIONS.

Make electrical connections between the fixture cable **[E]** and the main power **[F]** using wire nuts (by others).


Fit the wire nuts and wiring inside the junction box.


Warning: A luminaire with more than one power supply connection means shall be connected to only one branch circuit.



4 INSTALL HOUSING ASSEMBLY.

Place the housing assembly [B] over the direct feed bracket [C] and tighten the set screws [A].








Wall


WIRING DIAGRAMS (1 Circuit)

For electrical connections, follow the wiring diagrams according to specified drivers in product configuration.


INTEGRAL DRIVER - STATIC WHITE, SOLA



REMOTE DRIVER - STATIC WHITE, SOLA




RD1 / RELD1 / RELD0 / RSD1 BLACK НОТ POWER MMMNEUTRAL WHITE INPUT - HOT GREEN GROUND – NEUTRAL PURPLE DIM (+) 0-10V -GROUND PINK or GRAY DIM (-) 0-10V - DIM (+) 0-10V — DIM (-) 0-10V ТО DRIVER







Wall

REMOTE DRIVER - DUO





RDMX



Note:

- Must follow DMX wiring architecture
- Use low capacitance wiring for DMX network

