

LUMENWERX

CLUSTER COMBO

PENDANT - INSTALLATION INSTRUCTIONS

1

SINGLE FIXTUEER - CABLE

2

SINGLE FIXTURE - STEM

2

CONTINUOUS RUN - CABLE & STEM



This product must be installed in accordance with the National Electrical Code and all applicable local codes, by a person familiar with the construction and operation of the product, and the hazards involved. proper grounding is required for safety.

Ce produit doit être installé suivant le code national de l'électricité, ainsi que tous les codes locaux applicables, par une personne familière avec la construction et le fonctionnement du produit, ainsi que tous les risques qui y sont associés. La mise à terre électrique est obligatoire pour la sécurité.

Wire dimming conductors as Class 1

A luminaire with more than one power supply connection means shall be connected to only one branch circuit.

Do not power until all luminaires have been connected to the remote driver.

SINGLE FIXTURE - CABLE


Wire dimming conductors as Class 1



This product must be installed in accordance with the National Electrical Code and all applicable local codes, by a person familiar with the construction and operation of the product, and the hazards involved. proper grounding is required for safety.

Ce produit doit être installé suivant le code national de l'électricité, ainsi que tous les codes locaux applicables, par une personne familière avec la construction et le fonctionnement du produit, ainsi que tous les risques qui y sont associés. La mise à terre électrique est obligatoire pour la sécurité.


1



Locate ceiling mounting points according to supplied client drawing. Make a knot in the power cord (A) and then connect it to the ceiling power feed. **Number of wires may vary. A luminaire with more than one power supply connection means shall be connected to only one branch circuit.**

2


POWER SIDE



Secure canopy (B) with slip ring (C) on threaded rod (D).


3

NON-POWER SIDE




Secure canopy (E) with cable coupler (F) on crimp strud (1/4\"-20) (G) (by other).







4



Insert the aircraft cable (H) into the griplock (I). Adjust the cable (H) length by pushing the feeder tube (J) and **cut the excess cable** with an aircraft cable cutter (K). Secure power cord (A) to aircraft cable (H) with plastic clip (L).



SINGLE FIXTURE - STEM



CONTINUOUS RUN - CABLE & STEM

Note: Images are shown with CABLE and apply to STEM too.

