
WALL MOUNT - INSTALLATION INSTRUCTIONS





www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to LumenWerx ULC.


FILE NAME:AXLE-WALL-MOUNT-INST

November 8, 2019 Page: 1/5

Intertek

WALL MOUNT - INSTALLATION INSTRUCTIONS





www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to LumenWerx ULC.

FILE NAME:AXLE-WALL-MOUNT-INST


November 8, 2019 Page: 2 / 5

Intertel

screws (C).

WALL MOUNT - INSTALLATION INSTRUCTIONS





www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to LumenWerx ULC.

FILE NAME:AXLE-WALL-MOUNT-INST

screws.


November 8, 2019 Page: 3 / 5

Intertel


them.

WALL MOUNT - INSTALLATION INSTRUCTIONS








Screw the arm mounting plate (F) directly to the wall, using drywall screws (by others); and drywall anchors (by others) when needed.





Push the cover plate (G) to the fixture's arm mounting plate and fix it using set screws (H) (6/32 Alan key needed). The set screws (H) should be flush with the cover plates (G).












FILE NAME:AXLE-WALL-MOUNT-INST

November 8, 2019 Page: 4 / 5

LumenWerx ULC. reserves the right to change or modify product specifications without notification

WALL MOUNT - INSTALLATION INSTRUCTIONS





Page: 5 / 5

November 8, 2019

LumenWerx ULC. reserves the right to change or modify product specifications without notification -