


**IMPORTANT:** Installation instructions are shown with Pop Round and applies to all Pop Round and Pop Square fixtures


**NOTE:** Wire dimming conductors as Class 1

### 1 FLUSH & REGRESSED




Push the lens (A) up and guide it out of the housing (B).

### 2




Unscrew the LED plate holder (C) to get access to the driver (D). Disconnect quick connectors (E) between driver and LED board. Remove security cable (G).

### 3




Disconnect wires from the driver (D) to the power and to the quick connector.

### 4




Unscrew the driver (D) from the housing (B). Replace the driver and reconnect the wires from the power and from the quick connector.

### 5



Attach security cable (G). Make wires connection between the driver and the LED board by connecting quick connectors (E). Screw the LED plate holder (C) back in place.

### 6




Align and tilt the lens (A) to insert it back into the housing (B).

**IMPORTANT:** Installation instructions are shown with Pop Round and applies to all Pop Round and Pop Square fixtures


**NOTE:** Wire dimming conductors as Class 1

### 1 DROP




Pull down the diffuser (H) to get access to the springs (I). Squeeze the springs (I) to release them from the brackets (J). Once all the springs (I) have been released, slowly lower the diffuser (H) retained by security cable (G).

### 2




Disconnect quick connectors (E) between driver and diffuser (H). Remove security cable (G).

### 3




Unscrew and remove the driver box (K).

### 4




Disconnect wires from the driver (D) to the power and to the quick connector.

### 5





Unscrew the driver (D) from the housing (B). Replace the driver and reconnect the wires from the power and from the quick connector.

### 6





Screw back in place the driver box (K).

7



Attach security cable (G). Make wires connection between the driver and the diffuser (H) by connecting quick connectors (E).

8



Squeeze, align and insert the springs (I) into the brackets (J) that are further inside the housing. Once all the springs (I) are properly installed, slowly push the diffuser (H) in the housing (B) as far as the brackets (J) allow.