
PENDANT STEM - INSTALLATION INSTRUCTIONS



IMPORTANT: Installation instructions are shown with Quad Narrow and applies to all Quad sizes


1 SINGLE FIXTURE



Make sure that the power to the fixture is turned off. Slide the slip ring (A) and the canopy (B) onto the stem (C) and leave some space. Screw the junction box crossbar (D) with the threaded rods (E) onto the stem (C).


Screw the stems (C) onto the nipple at the ends of the fixture (F).

2 FOR EMERGENCY CIRCUIT



In the case where an <u>emergency circuit</u> is required, the wires to the emergency circuit will be passed through a second stem.


5 POWER SIDE



Raise the fixture and tighten the junction box crossbar (D) with screws to the junction box (G). Make wire connection with wire connectors (H). Then slide the canopy (B) and thighten the set up with the slip ring (A).


NOTE: Wire dimming conductors as Class 1

FOR FIXTURE IN GRID CEILING



In the case where the luminaire is installed on a **grid ceiling**, the power cable will pass outside of the stem.

6 NON-POWER SIDE



Raise the fixture and tighten the junction box crossbar (D) with screws to the junction box (G). Then slide the canopy (B) and thighten the set up with the slip ring (A).

www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 @ All rights are reserved to LumenWerx ULC.

FILE NAME:QUAD-PENDANT-STEM-INST

November 14, 2019


Page: 1 / 3


QUAD N-W


mounting hardware.


PENDANT STEM - INSTALLATION INSTRUCTIONS













crossbars (D) with screws to the junction boxes (G). Make wire connection on the power side with

thighten the sets up with the slip rings (A).

wire connectors (H). Then slide the canopies (B) and






QUAD N-W

PENDANT STEM - INSTALLATION INSTRUCTIONS







November 14, 2019