
### LUMENWERX


#### NOTE: Wire dimming conductors as Class 1





This product must be installed in accordance with the National Electrical Code and all applicable local codes, by a person familiar with the construction and operation of the product, and the hazards involved. proper grounding is required for safety.

Ce produit doit être installé suivant le code national de l'électricité, ainsi que tous les codes locaux applicables, par une personne familière avec la construction et le fonctionnement du produit, ainsi que tous les risques qui y sont associés. la mise à terre électrique est obligatoire pour la sécurité.











Make sure the power to the fixture is turned off. Bend the tabs (A) on the end of the fixture. For a continuous system, leave tabs close. Power feeds must be brought to the master fixture.



Remove ceilling tiles (B) where the fixture will be installed as well as the adjacent tiles for easy access during installation.



www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 @ All rights are reserved to LumenWerx ULC.


FILE NAME:RIZE-GRID-INST-REV2


May 5, 2021

Page: 1/3


#### **GRID CEILING - INSTALLATION INSTRUCTIONS**

## LUMENWERX








Remove power plate (H) from fixture and install BX connector (G) (by other) and BX cable (F) (by other) through the power plate. Tighten BX connector (G) screw. Connect cables from the BX cable (F) to the driver wires (I) using wire nuts (J). Number of wires may vary. Reinstall the power plate to the fixture.



To install the third power cable (K) (by other), repeat step 5. Number of wires may vary.







, ||

FILE NAME:RIZE-GRID-INST-REV2

May 5, 2021

satellite fixture (M). Remove the power plate (N)


and push the power knock out.

Page: 2/3

### **RIZE**

#### **GRID CEILING - INSTALLATION INSTRUCTIONS**

# LUMENWERX



Make the connection between low voltage connector (O) to the satellite fixture (M) quick connector (P). Install the BX connector (O) to the power plate (N). Reinstall the power plate (N) to the fixture (M).