
SIDEVIEW


DRIVER REPLACEMENT INSTRUCTION




NOTE: Wire dimming conductors as Class 1









Unscrew the wire nuts (D) on both side of the driver (C).




Unscrew and open the side cover (B) on the power



Unscrew the driver (C) from the side cover (B). Replace the driver, screw it back in place and make connections with wire nuts.





www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 @ All rights are reserved to LumenWerx ULC.

FILE NAME:SIDEVIEW-DRIVER-REPLACEMENT-INST

November 14, 2019

back to the fixture.

Page: 1/1

