

FORTEX2

WALL MOUNT - INSTALLATION INSTRUCTIONS


IMPORTANT: Installation instructions are shown with 4ft Fortex 2 and applies to all Fortex 2 sizes




Locate mounting points [*] on the wall according to the client drawings.









Remove lenses (B) and place them in a safe place.





NOTE: Wire dimming conductors as Class 1

Disconnect LED molex connector (C) by taking a pointed object and pressing on the two tabs on the top. Unscrew and remove LED cartridge (D) to get acces to the wall bracket.



www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to LumenWerx ULC.

FILE NAME:FORTEX2-WALL-SURFACE-MOUNT-INST


November 12, 2019 Page: 1/2





WALL MOUNT - INSTALLATION INSTRUCTIONS





www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to LumenWerx ULC.

FILE NAME:FORTEX2-WALL-SURFACE-MOUNT-INST

Page: 2 / 2

November 12, 2019