DRIVER REPLACEMENT INSTRUCTION




IMPORTANT: Installation instructions are shown with Quad Narrow and applies to all Quad sizes






Reflector must be reinstalled with the screw and plastic washer that was originally supplied. If not, it can result in an electrical failure

Make sure to reconnect the wires to the LED boards correctly







Make sure the power to the fixure (A) is turned off. Remove the lens (B).


NOTE: Wire dimming conductors as Class 1






Unscrew the cartridge (C) and place it in a safe place.







www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 @ All rights are reserved to LumenWerx ULC.

FILE NAME: OUAD-DRIVER-REPLACEMENT-INST

November 14, 2019

place. Do not apply too much pressure.

Page: 1/1



the driver and make connection with wire nuts.