
# **REVEN-CAMBER FLUORESCENT**


### PENDANT CABLE - INSTALLATION



# IMPORTANT: Installation instructions are shown with Reven and applies to Reven and Camber fixtures




Unscrew and remove the dust cover (A) if provided.




Install the lamps (B) and put back the dust cover (A) back in place.


# 3 SINGLE FIXTURE

Locate ceiling mounting points according to supplied client drawing. Make a knot in the power cord (X) and then connect it to the ceiling power feed.



to step 8.







Insert the aircraft cable (I) into the cable gripper (J) and repeat on both sides of fixture. Secure power cord to aircraft cable with plastic clip (K).

## **REVEN-CAMBER FLUORESCENT**

### PENDANT CABLE - INSTALLATION











(A) if provided and the side reflectors (N) using the

included tool. Repeat for all fixtures in the run.









in the run.

quick connectors (R). Repeat for all other fixtures

# **REVEN-CAMBER FLUORESCENT**

### PENDANT CABLE - INSTALLATION



