
AUDIA with ECHOCORE[™]

PENDANT - BLANK - STEM - INSTALLATION INSTRUCTIONS





www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to Lumenwerx ULC.

AUDIA-PENDANT-BLANK-STEM-INST-REV1


March 9, 2021 Page: 1/2






PENDANT - BLANK - STEM - INSTALLATION INSTRUCTIONS






Raise the fixture and tighten the junction box crossbar (D) with screws (by others) to the junction box (F). Then slide the canopy (B) and thighten the set up with the slip ring (A).



Install the aircraft cables on the first fixture. Then install it on the second fixture (as shown in step 4). Remove the screw (H) on the joiner and put it in a safe place.



Join fixtures using align pins as guide. Put back in place the provided screw (I) (using 3/16" Ball-End Screwdriver provided). Tight the screw (I) to pull the extrusions together. Repeat steps 5 and 6 for all others fixtures in the run.

