

## CUBITO












Unscrew the cartridge (C) and keep the screws in a safe place.



Disconnect LED molex connector (D) by taking a pointed object and pressing on the two tabs on the top. Remove the cartridge (C) and keep it in a safe place.



Number of wires may vary.



 B
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D
 D

Put back the reflector (C) in place and reconnect the wires to the LED molex connectors (D).

June 27. 2022

www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to LumenWerx ULC. | FILE NAME:CUBITO-LED-SURFACE-WALL-MOUNT-INST-REV1

inside the wall.


Interte


the wall. Align the screws (by other) with the studs

## **CUBITO**

## WALL/SURFACE - INSTALLATION INSTRUCTIONS







June 27, 2022 FILE NAME: CUBITO-LED-SURFACE-WALL-MOUNT-INST-REV1 Page: 2 / 3




www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to LumenWerx ULC.



## WALL/SURFACE - INSTALLATION INSTRUCTIONS







Page: 3 / 3

June 27, 2022

www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to LumenWerx ULC. | FILE NAME:CUBITO-LED-SURFACE-WALL-MOUNT-INST-REVI