FLAIR Pendant - Deep Round Canopy




This product must be installed in accordance with the National Electrical Code and all applicable local codes, by a person familiar with the construction and operation of the product, and the hazards involved. Proper grounding is required for safety. Ce produit doit être installé suivant le code national de l'électricité, ainsi que tous les codes locaux applicables, par une personne familière avec la construction et le fonctionnement du produit, ainsi que tous les risques qui y sont associés. La mise à terre électrique est obligatoire pour la sécurité. Wire dimming conductors as Class 1.




For electrical connections, follow the wiring diagrams on page <u>3 and 4</u> according to specified drivers in product configuration.


OVERVIEW


Junction box (by others)





Standard 4" octagonal junction box






Items list

Standard J-box (by others)
Mounting plate
Driver bracket
Deep round canopy
Cable
Stem

Tool required

- Philips screwdriver





www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to Lumenwerx ULC. Lumenwerx ULC. reserves the right to change or modify product specifications without notification. FLAIR-PENDANT-DEEP-ROUND-CANOPY-INST February 20, 2023

LUMENWERX

FLAIR Pendant - Deep Round Canopy

POWER CORD


1 MAKE ELECTRICAL CONNECTIONS AND FIX MOUNTING PLATE.

Remove screws **[A]** from the canopy assembly **[B]**.

Make electrical connections between the main power **[C]** and the driver **[D]** using wire nuts (by others).

Mount and turn the mounting plate **[E]** to place on the junction box **[F]**.

Tighten screws to secure the mounting plate **[E]** to the junction box.




2 MAKE ELECTRICAL CONNECTIONS.

Adjust the cable length by cutting and stripping the fixture cable **[G]** to the desired length for the height of the fixture.


Make electrical connections between the driver **[D]** and the fixture cable **[G]** using wire nuts (by others).


Warning: A luminaire with more than one power supply connection means shall be connected to only one branch circuit.



3 MOUNT CANOPY.


Place the canopy **[B]** over the mounting plate **[E]** and secure with the provided screws **[A]**.





Cable

Tighten the tapered nut [H].



Stem

Mount the stem **[I]** on the threaded nipple.



FLAIR-PENDANT-DEEP-ROUND-CANOPY-INST February 20, 2023


FLAIR Pendant - Deep Round Canopy

LUMENWERX


WIRING DIAGRAMS (1 Circuit)

For electrical connections, follow the wiring diagrams according to specified drivers in product configuration.


INTEGRAL DRIVER - STATIC WHITE, SOLA




REMOTE DRIVER - STATIC WHITE, SOLA



RD1/RELD1/RELD0/RSD1





RLDE1




DRIVER

RLTEA2W / RELV / RTRI / RSELV / RSTRI









www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to Lumenwerx ULC. Lumenwerx ULC. reserves the right to change or modify product specifications without notification.


Note:


FLAIR-PENDANT-DEEP-ROUND-CANOPY-INST February 20, 2023

FLAIR Pendant - Deep Round Canopy




REMOTE DRIVER - DUO





RDMX



- Must follow DMX wiring architecture

- Use low capacitance wiring for DMX network



www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to Lumenwerx ULC. Lumenwerx ULC. reserves the right to change or modify product specifications without notification.