

### PENDANT CABLE - INSTALLATION INSTRUCTIONS




## NOTE: Wire dimming conductors as Class 1






Locate ceiling mounting points according to supplied client drawing. Make a knot in the power cord (A) and then connect it to the ceiling power feed.




Insert the aircraft cable (H) into the cable gripper (I). Adjust the cable (H) length (cut it if needed). Secure the cable gripper (I) by tightening the safety nut on the gripper.

# 2 POWER SIDE



Secure canopy (B) with slip ring (C) on threaded rod (D).




Secure power cord (A) to aircraft cable (H) with plastic clip (J).

# NON-POWER SIDE G G

Secure canopy (E) with cable coupler (F) on crimp strud (1/4"-20) (G) (by other).

## CONTINUOUS SYSTEM




For a continuous system, repeat steps 1 to 3 for all mounting and 4-5 for the first fixture in the run.





# **PAZ**

## PENDANT CABLE- INSTALLATION INSTRUCTIONS











Slowly lift up the cartridge (G) on the female section with the provided lens tool. You should feel the cartridge popping out of the fixture.


Unscrew and remove the end plate (K) of the cartridge (G). Keep it in a safe place. Slightly slide the LED boards out of the cartridge. Disconnect LED molex connectors (L) by taking a pointed object and pressing on the two tabs. Then remove the cartridge (G) and keep it in a safe place.



Join fixtures using align pins as guide. Put back in place the provided screw (M) (using 3/16" Ball-End Screwdriver (O) provided). Make sure that no wires are placed in between the extrusions, preventing the fixtures to be joined. Tight the screw (M) to pull the extrusions together. Repeat steps 7 to 10 for all others fixtures in the run.



Reconnect the LED molex connectors (N). NOTE: connect black wire into the negative (-) terminal and the white wire into (+) positive terminal. Make sure that the wires are not obstructed any LED diode. Screw back the end plate (K) to the cartridge (G). Reinstall the cartridge (G).



vary. Push the wires inside the female fixture.

Insert and push the cartridge (G) back in place. Make sure the cartridge's springs are proprely placed onto the bracket (O). Make sure not to pinch the wires when placing the cartridge back.

