
PENDANT STEM- INSTALLATION INSTRUCTIONS




NOTE: Wire dimming conductors as Class 1






Make sure that the power to the fixture is turned off. Slide the slip ring (A) and the canopy (B) onto the stem (C) and leave some space. Screw the junction box crossbar (D) onto the stem (C).




Screw the stems (C) on the first fixture (E). Then install it on the second fixture.

FOR EMERGENCY CIRCUIT




In the case where an emergency circuit is required, the wires to the emergency circuit will be passed through a second stem.

POWER SIDE




Raise the fixture and tighten the junction box crossbar (D) with screws (by others) to the junction box (G). Make wire connection with electrical marettes (H). Then slide the canopy (B) and thighten the set up with the slip ring (A).

FOR FIXTURE IN GRID CEILING



In the case where the luminaire is installed on a grid ceiling, the power cable will pass outside of the stem.

NON-POWER SIDE



Raise the fixture and tighten the junction box crossbar (D) with screws (by others) to the junction box (G). Then slide the canopy (B) and thighten the set up with the slip ring (A).




mounting hardware.


install it on the second fixture.


PENDANT STEM- INSTALLATION INSTRUCTIONS




7 CONTINUOUS SYSTEM For a continuous system, repeat steps 1 to 3 for all










crossbars (D) with screws (by others) to the junction

boxes (G). Make wire connection on the power side

with electrical marettes(H). Then slide the canopies

(B) and thighten the sets up with the slip rings (A).


cartridge popping out of the fixture.




PAZ

PENDANT STEM- INSTALLATION INSTRUCTIONS






Join fixtures using align pins as guide. Put back in place the provided screw (L) (using 3/16" Ball-End Screwdriver (M) provided). Make sure that no wires are placed in between the extrusions, preventing the fixtures to be joined. Tight the screw (L) to pull the extrusions together. Repeat steps 11 to 13 for all others fixtures in the run.



Reconnect the LED molex connectors (J). NOTE: connect black wire into the negative (-) terminal and the white wire into (+) positive terminal. Make sure that the wires are not obstructed any LED diode. Screw back the end plate (I) to the cartridge (F). Reinstall the cartridge (F).



placed onto the bracket (G). Make sure not to pinch

the wires when placing the cartridge back.

Put the lens (I) back in place.



Page: 3 / 3