

# **PRIMO LED**


### GRID CEILING - WITH REMOTE BATTERY PACK





## NOTE: Wire dimming conductors as Class 1














for additional safety a security wire (E) can be

used to fix the fixture to the T-bar grid (C).


attached from the tabs (D) and a screw (F) can be

## **PRIMO LED**


### **GRID CEILING - WITH REMOTE BATTERY PACK**


national electrical codes.






Remove power plate (G) from fixture and install BX connector (H) (by other) and BX cable (I) (by other) trought the power plate. Tightened BX connector (H) screw.





power plate (G) onto fixture (B) by refastening

screws to power plate (G) and fixture (B).



If a remote battery pack (L) was ordered with fixture (B), place Remote battery pack not further than 50 ft from the fixture ( for an 18 gauge wire).

