

RIM VERSO ACOUSTIX

CANOPY DRIVER BOX - AC - INSTALLATION INST.

LUMENWERX
WWW.LUMENWERX.COM


IMPORTANT: Installation instructions are shown with RIMR24 and applies to all RIM VERSO

NOTE: Wire dimming conductors as Class 1




This product must be installed in accordance with the National Electrical Code and all applicable local codes, by a person familiar with the construction and operation of the product, and the hazards involved. proper grounding is required for safety.


Ce produit doit être installé suivant le code national de l'électricité, ainsi que tous les codes locaux applicables, par une personne familière avec la construction et le fonctionnement du produit, ainsi que tous les risques qui y sont associés. la mise à terre électrique est obligatoire pour la sécurité.




Slightly loosen the screws (A) on the side of the canopy (B). Remove the canopy plate (C).




Fix the canopy (B) to the junction box (D).



Use the canopy (B) as a model to mark 4 drill holes.



Remove the canopy. Drill holes (1/4" diameter) following the drill hole marks. Install #8 screw anchors (E).




Tighten the two screws to secure the canopy (B) to the Junction box (D).

RIM VERSO ACOUSTIX

CANOPY DRIVER BOX - AC - INSTALLATION INST.


LUMENWERX
WWW.LUMENWERX.COM

6




Use #8 screws to fasten the canopy (B) to the ceiling.

7




Pass the aircraft cables (G) through the canopy plate (C). Insert them into the grippers (F) then adjust the cables (G) by pushing the feeder tube (F). Cut the excess cable with an aircraft cable cutter (H). **RIM 36", 48" and 60" have 4 wires.**

8




Make electrical connections between the driver (I) and the main power (J) with electrical marettes (K). Push the wires inside the junction box (D). **Notes:** **Connect the green wire to your ground wire.** **Warning: Power must come from Single branch circuit.**

9




Pass the power cord (L) into the canopy plate (C) and make a knot. Make electrical connections between the power cord (L) and the driver (I) using quick connectors (M).

10



Secure the power cord (L) to the aircraft cable (G) with plastic clip (N). Put canopy plate (C) back in place turn to fix it.

11



Secure the canopy plate (C) onto the canopy (B) by tightening the two screws (A) on the sides.