

IMPORTANT: Installation instructions are shown with TOGO 24

NOTE: Wire dimming conductors as Class 1




This product must be installed in accordance with the National Electrical Code and all applicable local codes, by a person familiar with the construction and operation of the product, and the hazards involved. proper grounding is required for safety.


Ce produit doit être installé suivant le code national de l'électricité, ainsi que tous les codes locaux applicables, par une personne familière avec la construction et le fonctionnement du produit, ainsi que tous les risques qui y sont associés. la mise à terre électrique est obligatoire pour la sécurité.

1 REMOTE DRIVER BOX

Please refer to the remote driver installation sheet for more informations.




2




Loosen the decorative nut (A) on the canopy (B). Separate the canopy (B) from the canopy plate (C).

3




Fix the canopy plate (C) on the junction box (D).

4




Use the canopy plate (C) as a model to mark 4 red holes.

5




Remove the canopy plate. Drill holes (1/4" diameter) following the red marks. Install #8 screw anchors (E).

6




Tighten screws to secure the canopy (C) to the Junction box.

7




Use #8 screws to fasten the canopy (C) to the ceiling.

8




Pass all cables (F) through the canopy (B). Insert them into the grippers (G). Adjust the cables (F) by pushing the feeder tube (G). **Notes: Height adjustment of the fixture must be done at this step. TOGO 36" and 48" have 4 wires.**

9



cut the excess cable with an aircraft cable cutter (H). **Notes: Leave POC (Power Over Cable) length of 1.5" to make the connection inside the J-box.**

10



Make electrical connections between POC (Power Over Cable) (I) and the remote driver feed (J).

Notes: Make sure that you are connecting the negative (-) POC (as mark on the fixture with black color and a label) to your negative wire and the positive (+) POC (as mark on the fixture with red color and a label) to your negative wire. Warning : Power must come from a Single branch circuit.

