PENDANT STEM- INSTALLATION INSTRUCTIONS




NOTE: Wire dimming conductors as Class 1




Reflector must be reinstalled with the screw and plastic washer that was originally supplied. If not, it can result in an electrical failure


Make sure to reconnect the wires to the LED boards correctly



1 SINGLE FIXTURE




Make sure that the power to the fixture is turned off. Slide the slip ring (A) and the canopy (B) onto the stem (C) and leave some space. Screw the junction box crossbar (D) onto the stem (C).



In the case where an <u>emergency circuit</u> is required, the wires to the emergency circuit will be passed through a second stem.






In the case where the luminaire is installed on a **grid ceiling**, the power cable will pass outside of the stem.

4 C F

Screw the stems (C) onto the nipple at the ends of the fixture (F).

5 POWER SIDE



Raise the fixture and tighten the junction box crossbar (D) with screws (by others) to the junction box (G). Make wire connection with wire connectors (H). Then slide the canopy (B) and thighten the set up with the slip ring (A). Number of wires may vary.

www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 @ All rights are reserved to LumenWerx ULC.

FILE NAME:VIA1_5-PENDANT-STEM-INST


November 15, 2019

Page: 1/3

VIA 1.5


PENDANT STEM- INSTALLATION INSTRUCTIONS








junction box (G). Then slide the canopy (B) and


thighten the set up with the slip ring (A).












VIA 1.5


PENDANT STEM- INSTALLATION INSTRUCTIONS







crossbars (D) with screws (by others) to the junction boxes (G). Make wire connection on the power side with wire connectors (H). Then slide the canopies (B)


and thighten the sets up with the slip rings (A).







Join fixtures using align pins as guide. Put back in place the provided screw (L) (using 3/16" Ball-End Screwdriver (N) provided). Make sure that no wires are placed in between the extrusions, preventing the fixtures to be joined. Tight the screw (L) to pull the extrusions together. Repeat steps 11 to 13 for all others fixtures in the run.



Reinstall the cartridge (K) and reconnect the LED molex connector (J). **NOTE: connect black wire into the negative (-) terminal and the white wire into (+) positive terminal.** Make sure that the wires are not hiding any LED diode. Screw the cartridge back in place by using screw with plastic washer. **Do not apply too much pressure.**

