


## DRYWALL TRIMLESS - INSTALLATION INSTRUCTIONS




## NOTE: Wire dimming conductors as Class 1









Remove lens (A) with the included lens tool.



Install power cable (D) (by other) through the BX connector (E) (by other) and install onto the power plate (F) provided. Make electrical connections between power cable (D) and fixture cables using electrical marettes (G). Reinstall the power plate (G) to the fixture (H).




Disconnect LED molex connector (B) by taking a pointed object and pressing on the two tabs on the top.




Insert the fixture (H) into pre-cut hole in drywall, aligning threaded rods (I) with holes in top of fixture (H). Put washers (J) and tighten nuts (K) to secure the fixture (H).


## DRYWALL TRIMLESS - INSTALLATION INSTRUCTIONS








Reinstall the cartridge(s) (C) and reconnect the LED molex connector (B). **NOTE: connect black wire into the negative (-) terminal and the white wire into (+) positive terminal.** Make sure that the wires are not hiding any LED diode. Screw the cartridge back in place.
















safe place.

## DRYWALL TRIMLESS - INSTALLATION INSTRUCTIONS











Insert the second fixture (M) into pre-cut hole in drywall, aligning threaded rods (I) with holes in top of fixture (M). Put washers (J) and tighten nuts (K) to secure the fixture (M).



Remove the screw (L) on the joiner and put it in a

Join fixtures using align pins as guide. Put back in place the provided screw (L) (using 3/16" Ball-End Screwdriver (O) provided). Make sure that no wires are placed in between the extrusions, preventing the fixtures to be joined. Tight the screw (L) to pull the extrusions together. Repeat steps 13 to 16 for all others fixtures in the run.



Reinstall the cartridge (C) and reconnect the LED molex connector (B). NOTE: connect black wire into the negative (-) terminal and the white wire into (+) positive terminal. Make sure that the wires are not hiding any LED diode. Screw the cartridge back in place.

