PENDANT STEM- INSTALLATION INSTRUCTIONS




NON POWER SIDE


FOR FIXTURE IN GRID CEILING

POWER SIDE

NOTE: Wire dimming conductors as Class 1



Make sure that the power to the fixture is turned off. Slide the slip ring (A) and the canopy (B) onto the stem (C) and leave some space. Screw the junction box crossbar (D) onto the stem (C).



Screw the stems (C) onto the nipple at the ends of the fixture (F).


FOR EMERGENCY CIRCUIT **EMERGENCY** POWER SIDE POWER SIDE

required, the wires to the emergency circuit will be passed through a second stem.

In the case where an emergency circuit is

NON-POWER SIDE

the stem.




In the case where the luminaire is installed on a

grid ceiling, the power cable will pass outside of

Raise the fixture and tighten the junction box crossbar (D) with screws (by others) to the junction box (G). Then slide the canopy (B) and thighten the set up with the slip ring (A).

POWER SIDE



Raise the fixture and tighten the junction box crossbar (D) with screws (by others) to the junction box (G). Make wire connection with wire connectors (H). Then slide the canopy (B) and thighten the set up with the slip ring (A). Number of wires may vary.

www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 @ All rights are reserved to LumenWerx ULC.


FILE NAME:VIA2-PENDANT-STEM-INST


November 15, 2019

Page: 1/3


PENDANT STEM- INSTALLATION INSTRUCTIONS










If direct/indirect or indirect, also remove the top











Raise the fixtures and tighten the junction box crossbars (D) with screws (by others) to the junction boxes (G). Make wire connection on the power side with wire connectors (H). Then slide the canopies (B) and thighten the sets up with the slip rings (A).




PENDANT STEM- INSTALLATION INSTRUCTIONS









Join fixtures using align pins as guide. Put back in place the provided screw (L) (using 3/16" Ball-End Screwdriver (N) provided). Make sure that no wires are placed in between the extrusions, preventing the fixtures to be joined. Tight the screw (L) to pull the extrusions together. Repeat steps 11 to 13 for all others fixtures in the run.

