PENDANT STEM- INSTALLATION INSTRUCTIONS




IMPORTANT: Installation instructions are shown with Via 4 and applies to Via 3-4-5 NOTE: Wire dimming conductors as Class 1



Reflector must be reinstalled with the screw and plastic washer that was originally supplied. If not, it can result in an electrical failure

Make sure to reconnect the wires to the LED boards correctly




NON POWER SIDE


FOR FIXTURE IN GRID CEILING

POWER SIDE

SINGLE FIXTURE




Make sure that the power to the fixture is turned off. Slide the slip ring (A) and the canopy (B) onto the stem (C) and leave some space. Screw the junction box crossbar (D) onto the stem (C).




Screw the stems (C) on the first fixture (E). Then install it on the second fixture.

FOR EMERGENCY CIRCUIT



In the case where an **emergency circuit** is required, the wires to the emergency circuit will be passed through a second stem.

POWER SIDE



Raise the fixture and tighten the junction box crossbar (D) with screws (by others) to the junction box (G). Make wire connection with electrical marettes (H). Then slide the canopy (B) and thighten the set up with the slip ring (A).

In the case where the luminaire is installed on a grid ceiling, the power cable will pass outside of

the stem.

FILE NAME:VIA3-4-5-PENDANT-STEM-INST


November 15, 2019

Page: 1/3


VIA 3-4-5


PENDANT STEM- INSTALLATION INSTRUCTIONS








junction box (G). Then slide the canopy (B) and thighten the set up with the slip ring (A).














VIA 3-4-5

PENDANT STEM- INSTALLATION INSTRUCTIONS








crossbars (D) with screws (by others) to the junction boxes (G). Make wire connection on the power side

with electrical marettes(H). Then slide the canopies

(B) and thighten the sets up with the slip rings (A).







wire into the negative (-) terminal and the white wire into (+) positive terminal. Make sure that the wires are not hiding any LED diode. Screw the cartridge back in place by using screw with plastic

washer. Do not apply too much pressure.

