
RECESSED MOUNTING - INSTALLATION INSTRUCTIONS



NOTE: Wire dimming conductors as Class 1




www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to LumenWerx ULC.

FILE NAME:VIASPLASH-RECESSED-INST


November 16, 2019 Page: 1 / 4

RECESSED MOUNTING - INSTALLATION INSTRUCTIONS






Insert the fixture (C) onto the mounting brackets (B). If the fixture position need adjustments use adjusting nuts (G) on the mounting brackets (B). Put back in place the steel washers (E) (that are steel + rubber bonded together) and tighten well the nuts (D) to attach the fixture.




Make the electrical connections between the fixture wires (H) and the building wires (I) inside the fixture



Screw back in place the lens frame (A) making sure not pinching the security cables on the sides. Make sure all the screws are well tightened and the metal frame is slightly regressed inside the aluminum housing

November 16, 2019



www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to LumenWerx ULC.

FILE NAME:VIASPLASH-RECESSED-INST




Page: 2/4


LumenWerx ULC. reserves the right to change or modify product specifications without notification

brackets (B) inside the fixture (C).


RECESSED MOUNTING - INSTALLATION INSTRUCTIONS









Install the mounting brackets (B) according to the mounting points dimension in the client drawing.



Connect the 1/2" trade size liquid-tight conduit fitting (by others) (F) to the 7/8" hole provided. Make sure the fitting is well tightened. A nonmetallic liquid-tight flexible conduit system needs to be used (by others).



Insert the first fixture (C) onto the mounting brackets (B). If the fixture position need adjustments use adjusting nuts (G) on the mounting brackets (B). Put back in place the steel washers (E) (that are steel + rubber bonded together) and tighten well the nuts (D) to attach the fixture.



17 C

Push the wires of the second fixture inside the first fixture (C) throught the end cap hole and insert the second section (L) into pre-cut hole.

November 16, 2019



Page: 3 / 4


www.lumenwerx.com (T) 514-225-4304 (F) 514-931-4862 © All rights are reserved to LumenWerx ULC.

FILE NAME:VIASPLASH-RECESSED-INST


the fixture

RECESSED MOUNTING - INSTALLATION INSTRUCTIONS







Insert the second section (L) into the mounting brackets (B). If the fixture position need adjustments use adjusting nuts (G) on the mounting brackets (B). Put back in place the steel washers (E) (that are steel + rubber bonded together) and tighten well the nuts (D) to attach the fixture.



Reinstall the nuts (J) inside the second fixture (L) on the joiner to secure it. Tighten well the 2 joining screws and make sure the joining gasket is well compressed between the 2 extrusions.



November 16, 2019



Screw back in place the lens frame (A) making sure not pinching the security cables on the sides. Make sure all the screws are well tightened and the metal frame is slightly regressed inside the aluminum housing

